




Quick Start Guide

P8

v1.0, Dec 2024

Copyright © 2024 Point Mobile Co., Ltd. All rights reserved.


Point Mobile Co., Ltd. is the designer and manufacturer of mobile handheld devices.

The Point Mobile logo is a registered trademark and symbol of Point Mobile Co., Ltd.


Features and specifications are subject to change without prior notice.



Terminal Parts



- 1. Front camera
- 2. Magnetic stripe reader (MSR)
- 3. Speaker
- 4. USB connector
- 5. IC card reader (ICCR)
- 6. Touch Screen
- 7. LED indicator




- | | |
|------------------------------------|----------------------------------|
| 8. Hand strap holes (top / bottom) | 13. Power button |
| 9. I/O connector for cradle | 14. Function (Volume) button |
| 10. Thermal printer | 15. Battery cover release button |
| 11. NFC tapping area | 16. Battery cover |
| 12. Scanner | |

Product Standard Accessories


- P8 (with Battery pack)
- Power adapter
- USB type C cable
- LCD protection film

Battery Replacement

1. Press and pull up the battery cover release buttons to open.



2. **Install:** Insert the battery from the top side and push down.
Remove: Pull the bottom side of the battery.



3. Put the cover's bottom side to the terminal, and close it.
4. Press around the release buttons to close the cover firmly.


Paper Roll Installation

Paper roll (Thermal paper) recommendation


Width	58mm
Diameter	40mm

Install a paper roll

1. Pull up the printer cover's hole, and open the cover upward.
2. Put the paper roll into the printer in the correct orientation.




3. Close the printer cover firmly. The end of the paper roll should be unrolled and extended outside the printer cover.




SD / SAM Card Installation


1. Open the battery cover and take off the battery to reveal the card slots.



2. Insert the card into the proper card slot with the gold contact facing down.



Turning on / off



Turn on


Press and hold the power button on the right side of the P8 until the screen turns on.

Turn off

When the display is on, press and hold the power button until the power menu is shown.

Then, tap **Power off**.

Charging the Terminal




1. Plug the USB type C cable to the power adapter.
2. Connect the cable to the USB connector of the P8.
3. Provide power by plugging the power adapter to the wall socket.

< Caution >

1. *Always use an original power supply from Point Mobile. Other chargers and cables may damage the P8.
The terminal warranty does not cover any damage caused by the usage of non-original power supplies.*
2. *Make sure the charger and cable is not wet.*
3. *Charge in temperatures from 0°C to 40°C.*

Payment


Magnetic card



Swipe the card at a proper and steady speed.

Magnetic strip must be facing down.


IC card



Insert the card and wait for completing the transaction.

IC chip must be facing up.

Contactless



Bring the card close to the NFC logo on the printer cover.

Keep the position during the transaction.

Scan a Barcode

Scanner is equipped on the top of the P8.

Center the red square aimer over the barcode. The barcode must be within the illumination square. You can tilt the aimer slightly for a comfortable angle to scan.



< Note >

If you want to trigger a scanning with the yellow function button on the right side, go to **Settings > Barcode Utility > Scan Setting**, and turn on **Right ScanKey** switch.